



Buttons and Ports Labeled



- | | | |
|---------------------------|-----------------------------------|-----------------------|
| ❶ Input indicator light | ❷ Input selection button | ❸ Gain switch |
| ❹ Output selection switch | ❺ Power switch/Volume knob | ❻ RGB indicator light |
| ❼ 6.35mm headphone output | ❽ 4.4mm balanced headphone output | |



- | | | |
|------------------------|-------------------------|-----------------|
| ❹ Single-ended line-in | ❺ Single-ended line-out | ❻ Coaxial input |
| ❼ Optical input | ❽ USB input | ❹ Power input |

Operation Explained

1. Turn on/off

Turn the “Power/Volume” knob until a click sound is heard to turn on the device; keep turning clockwise to increase the volume. Turn anticlockwise to decrease the volume; turn anticlockwise until a click sound is heard to turn off the device.

2. RGB indicator

*The RGB light in
*Different RGB lig
details, please vis

3. Output selecti

LO : rear p
PRE : rear p
PO : front

OUTPUT

Notes and P

- ★In case of syste
- power cable to re
- ★Please adjust t
- headphones so a
- ★Please do not v
- may be a sudden
- ★Please do not n
- water.
- ★You may be un
- it is not recomme

